



HOW TO: PICO SYSTEM UPDATES

Skills^{VR} Headset Support Guide | PICO



STEP-BY-STEP GUIDE

System Updates

Updating your PICO system ensures you're getting the latest features and improvements. Here's how you can manage the upgrade process:

» **Checking for Updates**

There are two ways to check for system updates:

- **Manual Check:** Go to Settings > General > System Version or navigate to Library > System Upgrade. Check for available updates.
- **Auto Check:** The system will automatically check for updates every time the device is turned on or reconnected to WiFi. If an update is available, you'll get a pop-up notification.

» **Installing the Update**

- **Online Upgrade:** When you receive a pop-up notification for a new update, tap the Online Upgrade button. The system will download the latest version. Once the download is complete, your PICO will automatically restart and install the update.
- **Offline Upgrade:** If you're manually updating, download the latest system version and place the installation package in your download folder. Tap the Offline Upgrade button in the pop-up notification. The system will check for the new version, and if it's newer, the update process will begin and the device will restart.

Still can't find the
**answer you're looking
for?**

Contact Support



www.skillsvr.com
support@skillsvr.com