



# CONNECTING YOUR PICO TO WI-FI

Skills<sup>VR</sup> Headset Support Guide | PICO




## STEP-BY-STEP GUIDE

# Connecting Your Headset to a Wi-Fi Network

### Connecting to Wi-Fi

- » Turn on the headset and go to the main menu.
- » Click on the Settings icon at the bottom menu.
- » In the settings menu, select WLAN.
- » Choose the Wi-Fi network you want to connect to.
- » Enter the Wi-Fi password and click Connect.
- » Now your Pico device should be connected to the Wi-Fi network.



### Having trouble connecting your Meta Quest to Wi-Fi? Try these simple tips to get back online:

- » Check Your Wi-Fi: Ensure your network is up and running, and verify that other devices can connect without issues.
- » Verify Your Password: Double-check that you're entering the correct Wi-Fi password.
- » Stay Within Range: Make sure you're within a reasonable distance from your Wi-Fi router to avoid connection drops.
- » Avoid Public Hotspots: If you're setting up your headset for the first time, stay away from public networks (like hotel or airport Wi-Fi) as they may cause issues.
- » Restart Your Headset: Sometimes a quick reboot is all it takes to fix connection problems.

**Still not connecting? Try switching to a different Wi-Fi network if possible. If your Meta Quest connects to that network, the issue could be with your original Wi-Fi settings.**

Still can't find the  
**answer you're looking  
for?**

Contact Support



[www.skillsvr.com](http://www.skillsvr.com)  
[support@skillsvr.com](mailto:support@skillsvr.com)